

FIG.1








FIG.4

- 1) rx200303200945p001
- 2) rx200303200945p002
- 3) rx200303200945p003
- 4) rx200303200946p004
- 5) rx200303200947p005
- 6) rx200303200947p006
- to) rx200303200947





FIG.6






FIG.8






FIG.12(a) FIG.12(b) My computer **FAX HISTORY** 3.5inch FD (A:) 「FAXTX」 Disk (C:) CD-ROM (D:) [FAXRX] **[FAXLOG]** Removable disk (E:) Removable disk (F:) **FAX HISTORY** [FAXTX] [FAXRX] [FAXLOG]

FIG.9





**FIG.11** 

